

1 Configure DriveKey

Remove DriveKey from it's packaging and switch the dip-switches as follows:

JAP	ON	ON
USA	OFF	ON
EUR	ON	OFF
KOR	OFF	OFF



2 Open your Wii

With a tri-wing screwdriver, remove the Wii cover, exposing the DVD drive.



3 Disconnect the DVD drive

Lift the hinge and gently pull out the cable from the DVD drive



MODGEEKSTORE.COM


4 Connect the DVD drive to DriveKey

Insert the included cable gently (pins face down) into both the DVD drive and DriveKey (at the end marked "DVD") and close the hinge.



5 Connect the Wii to DriveKey

Insert the cable previously removed from the DVD drive into the other end of DriveKey (at the end marked "Wii") and close the hinge.



6 Insulate DriveKey, close your Wii cover & enjoy!

Stick a few strips of insulating tape over DriveKey to keep it out of contact with the chassis, replace the DVD drive and close the Wii cover. You will now be able to play backups (copies) of your favorite Wii titles as well as imported originals from other regions! It's as easy as that!

Important Information

- Beware of other-region updates
- How to burn discs for DriveKey

Other useful stuff

- DriveKey Feature List
- Get DriveKey!

